

Fabric Ironing Tips

FABRIC	TEMP	STEAM	TIP
Denim	Max	Max	Iron while still damp
Linen	High to Max	Med to High	Iron while still damp on reverse side of fabric
Cotton	High	Med to High	Iron while still damp
Corduroy	High	Med	Iron on reverse side of fabric and then brush fibres softly.
Wool	Med	Med	Iron on reverse side of fabric and then brush fibres softly.
Wool Blends	Med	Med	Iron on reverse side of fabric and then brush fibres softly.
Cotton Blends			Take care to use the setting for appropriate the most delicate fabric of the blend.
Silk	Low	Low	Iron on reverse side of fabric with an ironing cloth.
Viscose	Low	None	Mainly dry iron
Rayon	Low	None	Iron on reverse side of fabric
Polyester	Low	None	Iron on reverse side of fabric
Nylon	Extra Low	None	Iron on reverse side of fabric
Acetate	Extra Low	None	Iron while still damp on reverse side of fabric
Acrylic	Extra Low	None	Iron on reverse side of fabric